

THE
BARRETO
MODEL 912
HYDRAULIC TRENCHER

CONGRATULATIONS!

You are now the proud owner of the BARRETO Model 912 trencher. Please take a moment of your time to look over the following information. Familiarize yourself with the trencher, its characteristics, and method of operation. Pay particular attention to the safety and operating instructions.

If you have any questions or need any replacement parts in the future, please contact us at your convenience. Our toll-free phone number, fax and email are listed below.

THANK YOU for your patronage and confidence in BARRETO equipment.

Barreto Manufacturing, Inc.
Innovative Equipment Engineered to Last
66498 Hwy 203, La Grande, OR 97850
(800) 525-7348 (541) 963-7348
FAX (541) 963-6755
E-Mail: info@barretomfg.com
Web Site: <http://www.barretomfg.com>

912 TRENCHER ASSEMBLY INSTRUCTIONS

1. Remove trencher from shipping crate.
2. Install boom onto boom pivot/mount. Push boom on as far as it will go. Be sure adjuster screw is backed out.

SERVICE INFORMATION

1. Your trencher should arrive with 10 gallons of hydraulic fluid in the tank. Check reservoir level using sight glass on the right side of the tank. If required, add to reservoir with tractor transmission hydraulic oil. (Shell DONAX TD FLUID or comparable.)
2. Recheck oil level after trencher has been run and oil has circulated through wheel and chain motors. Routinely check level thereafter.
3. Change hydraulic oil filter after the first 50 hours of use. Change it every 200 hours thereafter.
4. Add 1 quart of hydraulic oil to reservoir with each filter change.
5. Check all hydraulic fittings for leaks and tighten if necessary.
6. The grease zerk on chain shaft housing should be greased after every 4 to 8 hours of use. The grease zerk in the front wheel should be greased after every 8 hours of use.
7. Grease zerks on cylinder rod end and boom pivot should be greased daily.
8. Grease zerks on each side of the boom cylinder and on front wheel hub should be greased once a week
9. Grease zerks on the wheel hubs and hub lock screws should be greased and freewheeled once a week or so, depending upon free wheel use.


(See page 10 for illustrations of lubrication points.)

IMPORTANT: The engine on the Barreto trencher is normally serviced prior to shipping. However, shipping regulations may prohibit shipping with fuel or oil in the machine. Check levels and add oil and fuel as required before starting engine. Service engine according to the engine manual before starting.

WARNING: Running the trencher without hydraulic oil will cause serious damage to the hydraulic pump. **INSURE THAT THE RESERVOIR OIL LEVEL IS TO THE SIGHT GLASS BEFORE STARTING THE MACHINE.**

CHAIN INSTALLATION

1. Slide chain under sprocket, with teeth in the correct cutting direction. Properly installed, the cutting edges of the chain will face forward on the top of the boom and rearward on the bottom of the boom (see diagram below).
2. Push digging boom control lever forward to lower boom onto the chain.
3. Wrap chain around boom and sprocket. Install chain master link or link pin.
4. Use boom adjuster screw to tighten chain. Chain should have enough slack to allow approximately 1" to 2" of space between middle of boom and chain when boom and chain are straight out in a horizontal position.
5. Tighten adjuster screw locknut.



912 TRENCHER OPERATING INSTRUCTIONS

READ SAFETY INSTRUCTIONS BEFORE OPERATING!

Be sure that the engine oil, fuel and hydraulic oil are at proper levels before starting the engine.

STUDY AND UNDERSTAND CONTROLS BEFORE BEGINNING OPERATION.

1. **FREE WHEELING HUBS:** To engage either hub, turn the lock pin handle in (clockwise). This allows the spring-loaded pin to engage. Repeat for the other wheel. Push the trencher a bit if necessary until each pin finds a hole to drop into. The hubs are now locked. Disengaging one hub makes it much easier to turn the trencher when transporting under power.
2. **ENGINE IGNITION:** Must be in ON position to start the engine. Move to OFF position to stop the engine.
3. **ENGINE THROTTLE:** Controls engine speed. Operate at full throttle.
4. **CLUTCH LEVER:** Squeeze to activate the Wheel Drive and Dig Chain. All motion stops when the lever is released. It is located on the left handlebar.
5. **WHEEL DRIVE CONTROL:** Controls travel direction and speed. Very slow speed is required for trenching in most conditions. Begin trenching with the wheel control in neutral. Then adjust the reverse speed when trenching.
NOTE: Be sure operator understands that the machine moves BACK when trenching, not forward.
6. **DIG CHAIN ON/OFF CONTROL:** To trench, hold lever in ON position while clutch lever is activated. The ON/OFF lever will stay in position as long as the clutch lever is held. This automatically will activate the CHAIN FORWARD/REVERSE LEVER to FORWARD position.
7. **CHAIN FORWARD/REVERSE LEVER:** Use this lever to reverse chain to help clear debris from the chain. The clutch lever must be released to put the chain lever in reverse.
8. **DIGGING BOOM CONTROL:** Pull to raise the digging boom and push to lower the boom. During normal operation you will hear a relief valve working.

GETTING STARTED:

1. Start and warm up engine.
2. Put Wheel Drive control in neutral.
3. One wheel hub may be disengaged (free wheeling) for easier steering before driving machine to work location.
4. Squeeze the clutch lever and change the Wheel Direction Control to desired speed and direction.
5. Adjust the wheel speed and navigate the trencher to the starting position. The trencher is designed to dig toward the operator (with the Wheel Drive Control in reverse). With this in mind, position the machine to start the trench.

TRENCHING PROCEDURE:

1. Put Wheel Drive Direction Control in neutral
2. Be sure both hubs are engaged.
3. Have engine at full throttle (forward).
4. Hold Dig Chain On/Off Control in On position.
5. Squeeze the clutch lever.
6. Slowly lower the digging boom until the desired trench depth is achieved.
7. Put Wheel Drive Control in reverse. Start at slow speed.
8. Adjust the wheel speed until a workable speed is reached. Use a very slow speed for trenching and adjust for soil conditions as necessary. If objects such as rocks or roots jam in the chain, release the clutch lever, then reverse the chain to dislodge the debris. If necessary move the trencher forward a few inches and trench the area again.

BARRETO HYDRAULIC TRENCHER SAFETY INSTRUCTIONS

- **READ SAFETY AND OPERATING INSTRUCTIONS BEFORE OPERATING!**
- **USE COMMON SENSE AND PLENTY OF IT!**
 - Do not leave trencher unattended with the engine running.
 - Always leave trencher parked on a level surface, and lock the hubs.
- The **SAFETY CLUTCH LEVER** on the left handle bar is for operator protection. **DO NOT TAPE DOWN LEVER** or otherwise by-pass this safety feature.
- Objects may become airborne while operating trencher. Wear safety goggles and a hard hat while operating or observing!
- Digging chain, auger and other moving parts can cut off arms, legs, or fingers. **STAY CLEAR!**
- Buried cables or gas lines can cause serious injury or death if struck with dig chain. Contact local agencies for location before digging.
- Fuel exhaust and fuel fumes can cause illness or death. Operate outdoors and avoid breathing exhaust and fumes.
- Fuel fumes can catch fire or explode. Do not smoke or operate near flames or sparks.
- Hydraulic oil is under extreme pressure and can get under skin and burn or poison. Check for leaks with cardboard.
- Muffler and engine get hot enough to cause serious burns. Do not touch until cool.

BARRETO MANUFACTURING, INC. EQUIPMENT WARRANTY

Barreto Manufacturing, Inc. warrants all BARRETO equipment to be free of defects in material and workmanship for a period of one (1) year, dating from delivery to the original user.

This Warranty is in lieu of all other warranties, whether written or implied, and is limited to:

1. Replacement of parts returned to the dealer and/or factory and determined defective upon inspection. (Replacement for parts to dealers shall be at dealer cost plus shipping charges.)
2. Time for pick-up and/or delivery, transportation or service calls by dealers is excluded. Manufacturer reserves the right to determine reasonable time required for repair.


Warranty does not apply to damage caused by abuse or neglect. Time and materials required for normal maintenance and service are also excluded from warranty coverage.

Engines, engine accessories and tires are warranted by the original manufacturers and are not covered by the Barreto Equipment Warranty.

WHEEL DRIVE VALVE CABLE ADJUSTMENT


The clutch cable and lever must have some free play. The cable will stretch and occasionally needs adjustment.

1. Rotate the actuator arm clockwise, by hand, to take up any free play. Measure the distance from the pin of the actuator arm to the end of the cable housing.
2. Pull the clutch lever all the way up until it touches the handle bar grip. With the lever pulled up, again measure the distance from the pin of the lever to the cable housing. Calculate the difference.
3. Adjust the cable for $7/16"$ to $1/2"$ movement of the actuator arm at the pin. Do not include any lever free play in the measurements.




WHEEL DRIVE NEUTRAL ADJUSTMENT

The speed control cables may need to be adjusted after some use. If the machine creeps while the speed control is in neutral, the speed cables will need adjustment. Adjust the cables to bring the pump cable arm to the neutral position (vertical) when the speed control also is in neutral. Adjust the cables to eliminate slack, but do not over tighten them so they are extremely tight against each other.




CHAIN VALVE ADJUSTMENT

The chain valve control should be adjusted to completely activate the chain valve when the dig chain control is in 'ON' position. To check this adjustment, put the chain on/off control in ON position (with engine stopped). Pull the clutch lever on left handlebar up until it touches the handgrip. While holding clutch lever up, push on the chain forward/neutral/reverse lever. It should be at the end of its stroke, thus not move down any more. If the chain F/N/R lever can be pushed down more, the valve spool lever should be adjusted. To adjust, remove back cover from the control panel. Loosen the 2 bolts on valve lever and rotate the lever plate down about $1/16"$. Re-tighten the bolts and check the lever stroke. Adjust so the valve lever comes to the end of its stroke just as the clutch lever touches the handgrip when chain valve control is in ON position.



Daily Lubrication Requirements

Be sure to grease all lubrication points as outlined on page 2 of this manual.



912 TRENCHER TROUBLE SHOOTING GUIDE

CAUTION!! Always use extreme care when trouble shooting or making adjustments on trencher. Stay clear of chain and auger when engine is running. Stop engine before disassembling any component.

A. Entire hydraulic system does not operate and the engine is not under load.

- | | |
|---|--|
| 1. Broken or improperly adjusted clutch (actuator) cable. | See clutch cable and actuator arm adjustment. Adjust or replace cable. |
| 2. Low hydraulic oil in tank | Add oil until it shows in sight gauge. |
| 3. Hydraulic pump-to-engine coupler has slipped. | Check for wear and replace both coupler halves and rubber spider, as needed. |

B. Engine lugs down or dies and wheels and chain do not turn.

- | | |
|--|--|
| 1. Rocks or other obstructions stopping chain. | Reverse chain momentarily to free it from obstruction. Raise boom and stop chain. See if obstruction can be removed from trench. |
| 2. Trenching depth or speed too great for soil conditions. | Decrease ground speed or trenching depth. |
| 3. Engine improperly tuned or maintained. | See engine manual and correct as needed. |
| 4. Low oil alert causes engine to shut down. | This may occur when trenching on hills. Level trencher, check oil and allow oil alert to reset. |
| 5. Engine losing power due to wear. | See engine manual. |

912 TRENCHER TROUBLE SHOOTING GUIDE (Continued)

CAUTION!! Always use extreme care when trouble shooting or making adjustments on trencher. Stay clear of chain and auger when engine is running. Stop engine before disassembling any component.

C. Chain fails to rotate, but wheel drive works.

- | | |
|--|--|
| 1. Chain motor worn | Rebuild motor or replace with exchange motor. |
| 2. Chain Control Relief Valve Malfunctioning | Adjust Relief Valve to 2200 psi or replace relief spring if needed |

D. Wheels fail to turn, but chain rotates.

- | | |
|--|---------------------------------------|
| 1. Hubs unlocked. | Lock the hubs |
| 2. Wheel axle key sheared | Replace key and other parts as needed |
| 3. Wheel Drive Valve not fully activated | Adjust valve cable as shown on page 7 |
| 4. Speed Cable broken or disconnected | Replace or re-connect cable |
| 5. Pump Cable Lever loose on shaft | Tighten setscrew on Pump Lever |

E. Oil leaks in hydraulic system.

- | | |
|------------------------------------|---|
| 1. Fittings are loose | Tighten fittings on hoses and adapters |
| 2. Worn or broken hoses | Replace damaged hoses |
| 3. Oil around chain motor or shaft | Inspect motor for leaking shaft seal.
Rebuild motor or replace with exchange motor |

912 TRENCHER TROUBLE SHOOTING GUIDE (Continued)

CAUTION!! Always use extreme care when trouble shooting or making adjustments on trencher. Stay clear of chain and auger when engine is running. Stop engine before disassembling any component.

F. Foaming hydraulic oil coming from breather hose.

- | | |
|-------------------------|--|
| 1. Improper oil used. | Verify that hydraulic oil used had antifoaming additives. Recommended oil is tractor hydraulic. (Shell Donax TD or comparable) |
| 2. Air leaking into oil | Inspect and tighten fittings and clamps on pump and hoses |

G. Boom does not lift, or does not lower into ground.

- | | |
|--|--|
| 1. Boom lift relief valve malfunctioning | Adjust relief to 500 psi. This may require a replacement spring in valve |
|--|--|

TITLE: BODY ASSEMBLY		
PRODUCT LINE: TRENCHER 912 DATE 3/11/04		
SCALE: 1:8 DWG# 00247		
SHEET 1 OF 1		
REF. QTY.	PART NO.	DESCRIPTION
1	1	BODY
2	4	05068 WASHER, 5/16 SAE ZINC
3	8	05140 WHIZ LOCK, 5/16 x 3/4
4	1	10238 TRANSMISSION BRACE
5	1	10240 TRANSMISSION BRACE
6	2	10174 AXLE BEARING HOUSING
7	1	03014TR AXLE COUPLER
8	1	10231 AXLE, LEFT
9	2	03280 BALL BEARING, SKF 6206
10	2	10602 O-RING, 2-239, 3-7/8 OD X 1/8 SECTION
11	2	10211 O-RING, 2-143, 2-5/8 OD X 3/32 SECTION
12	2	05034 SNAP RING, 1-3/16 EXT, SH-118
13	4	03012 SEAL, AXLE
14	4	05606 SNAP RING, 1-1/8" EXTERNAL
15	1	03503 SIGHT GAUGE
16	1	10361 FITTING, 6409-8 PLUG
17	1	00268 TRANSMISSION ASSEMBLY
18	2	05199 KEY, 1/4 X 2-1/2 HARDENED
19	2	05018 KEY, 1/4 X 1-1/4 HARDENED
20	1	00249 MANIFOLD ASSEMBLY
21	1	00267 LID ASSEMBLY
22	1	00256 R1 WHEEL & HUB ASSEMBLY
24	4	05235 SH CAP SCREW, 1/4-28 NF X 3/4 G5 PLAIN
25	1	03040-57 DECAL, "HYDRAULIC OIL LEVEL"
26	1	03008 THRUST WASHER, 1.136 X 1.784 X .032 HARD
27	6	10623 O-RING, 2-010, 3/8 OD X 1/16 SECTION
28	6	10622 WHIZ LOCK, 1/4-20 UNC X 1-1/2
29	2	05044 GREASE ZERK, 1/4-28 UNF
30	1	04440-08 DECAL_912 S/N


BARRETO

O 03046 OPTIONAL WIDE TIRE, RIGHT
O 03047 OPTIONAL WIDE TIRE, LEFT

BARRETO

TITLE: MANIFOLD ASSEMBLY


PRODUCT LINE: TRENCHER 912 DATE 3/10/04
SCALE: 1:3 DWG# 00249
SHEET 1 OF 1



REF. QTY.	PART NO.	DESCRIPTION
1	1	02200 MANIFOLD, WHEEL MOTOR
2	4	03300 FITTING, 64094 PLUG
3	1	02201 SPOOL, DRIVE DUMP
4	1	10236 SPOOL SPACER
5	1	10237 SH CAP SCREW, 3/8-16 NC X 3/4 G5 PLAIN
6	1	03055 SPRING, VALVE SPOOL RETURN
7	1	03225 O-RING, 2-116N70, 15-.16 OD X 3/32 SECTION
8	1	03200 THRUST WASHER, .75 X 1 X .060, HARD
9	1	05216 SNAP RING, .34 EXTERNAL
10	1	04533 FITTING, 6801-8-8-LL
11	1	04210 FITTING, 6802-8-8
12	1	02203CT MANIFOLD SPACER
13	4	03226 O-RING, 2-112N70, 11/16 OD X 3/32 SECTION
14	4	05238 SH CAP SCREW, 5/16-18 NC X 3 G5 PLAIN
15	1	10614 QUAD RING #4-113
16	1	10470 QUAD RING #4-116

BARRETO


TITLE: HUB ASSEMBLY, SCREW LOCK
 PRODUCT LINE: TRENCHER 912 DATE: 3/23/04
 SCALE: 1/2 DWG# 00226
 SHEET 1 OF 1



REF.	QTY.	PART NO.	DESCRIPTION
1	1	10425	HUB, FREE WHEELING
2	1	02269	WHEEL HUB
3	1	05610	SNAP RING, SH-175, 1-3/4" EXTERNAL
4	2	03168	BUSHING, SLEEVE, NYLON, IGUS MSI-2832-12
5	1	06143	SET SCREW .25 NF X .25 CUP

TITLE: HUB & WHEEL ASSEMBLY, RIGHT
 PRODUCT LINE: TRENCHER 912
 SCALE: 1:4
 SHEET 1 OF 1
 DATE: 3/12/04
 DWG# 00225

BARRETO




REF. QTY.	PART NO.	DESCRIPTION
1	10419	HUB LOCK PIN
2	10421	LOCK PIN PLATE
3	10423	SPACER, HUB LOCK
4	10452	SPRING LEE LC-051G-9MW
5	05130	NUT, 1/2-20 NF ZINC
6	10424	CRIMP RING CRR-14
7	03190-FW	TIRE & RIM, FREE WHEELING, LEFT HAND
8	00226	HUB ASSEMBLY, SCREW LOCK
9	10422	HUB LOCK SCREW
10	10589	THRUST WASHER, .700 X 1.000 X .040 ZINC
11	10541	SNAP RING, 11/16 EXTERNAL
12	05044	GREASE ZERK, 1/4-28 UNF
13	03247	O-RING, 2-116E70 EPM, 15-16 OD X 3/32 SECTION
14	05042	NUT, LUG, 1/2-20 NF X 13/16 HEX

03046 6" WIDE TIRE OPTION

REF. QTY.	PART NO.	DESCRIPTION
1 1	10419	HUB LOCK PIN
2 1	10421	LOCK PIN PLATE
3 1	05042	NUT, LUG, 1/2-20 NF X 13/16 HEX
4 2	10423	SPACER, HUB LOCK
5 1	10452	SPRING LEE LC-051G-9MW
6 2	05130	NUT, 1/2-20 NF ZINC
7 1	10424	CRIMP RING CRR-14
8 1	03191-FW	"TIRE & RIM, FREE WHEELING, RIGHT HAND
9 1	00226	HUB ASSEMBLY, SCREW LOCK
10 1	10422	HUB LOCK SCREW
11 1	10541	SNAP RING, 11/16 EXTERNAL
12 1	10589	THRUST WASHER, 700 X 1.000 X .040 ZINC
13 1	05044	GREASE ZERK, 1/4-28 UNF
14 1	03247	O-RING, 2-116E70, EPM, 15-16 OD X 3/32 SECTION

03047 6" WIDE TIRE OPTION



BARRETO

TITLE: HUB & WHEEL ASSEMBLY, LEFT

PRODUCT LINE: TRENCHER 912

SCALE: 1:4

DATE 3/1/2014

SHEET 1 OF 1


DWG#

00227

BARRETO

TITLE: CONTROL VALVE ASSEMBLY

PRODUCT LINE: TRENCHER 912 DATE 8/24/04
SCALE: 1:4 DWG# 00259
SHEET 1 OF 1



REF. QTY.	PART NO.	DESCRIPTION
1	1	VALVE ROCKER
2	3	KNOB, 5/16-NC
3	2	CLEVIS PIN, 1/4 X 3/4 ZINC
4	2	RUE RING COTTER #8
5	2	WASHER, 1/4 SAE ZINC
6	1	WHIZ LOCK, 1/4-20 UNC X 5/8
7	1	05049 WHIZ LOCK, 1/4 X 3/4
8	2	03509 VALVE LINK W/PINS
9	1	04513-M VALVE RD-2508-M4, 2200 psi
10	1	10335 VALVE ENGAGE LEVER
11	1	10330 VALVE LEVER
12	1	04211 FITTING, 6801-8-10
13	2	04554 FITTING, 6801-8-8
14	1	04512-M VALVE RD-2508-T4, 500-650 PSI
15	1	04521 FITTING, 6407-10-10
16	2	04529 FITTING, 6410-8-6
17	1	04523 FITTING, 4601-12-10
18	2	04527-01 FITTING, 6801-4-6
19	2	03509S LEVER PIN
20	4	03509L SPOOL PIN
21	1	10553 CYLINDER VALVE LEVER
22	1	10773 NUT, GRIPCO, 1/4-20 NC GRB

BARRETO

TITLE: CONTROL ASSEMBLY


TRENCHER 912

DATE 3/10/04


SCALE 1:8

HEET 1 OF 2

DWG# 00260



REF. QTY.	PART NO.	DESCRIPTION	REF. QTY.	PART NO.	DESCRIPTION
1	1	10327 CONTROL POD	48	1	04440-07 DECAL: REV TRENCH SYMBOL
2	2	01403 HANDLE BAR SLUG	49	1	04440-05 DECAL: ENGINE SYMBOL
3	1	01402-R+ HANDLE BAR, RH	50	1	04440-04 DECAL: DIG CHAIN ON/OFF
4	1	01402-L+ HANDLEBAR, LEFT	51	1	03341-07 DECAL "IGNITION OFF/ON"
5	1	10332 LINK PIVOT	52	1	06420 ROCKER SWITCH, IGNITION OFF/ON
6	2	03501 BUSHING, IGUS MFI-0810-08	53	1	03806 QUICK-SPICE
7	1	10331 VALVE LINKAGE	54	1	06421 GROUND WIRE, IGNITION SWITCH
8	1	03505 CABLE, 4-1/2"	55	1	10603 IGNITION WIRE, 912
9	4	05273 NUT, NYLOCK, 5/16-18 NC ZINC	56	1	03009 HOUR METER - COMPLETE KIT
10	1	04217 FITTING, 4604-16-12			
11	4	05068 WASHER, 5/16 SAE ZINC			
12	2	05081 WASHER, 1/4 SAE ZINC			
13	4	05101 WASHER, 3/8 SAE ZINC			
14	4	05054 HH CAP SCREW, 5/16-18 NC X 1-3/4 G5 ZINC			
15	4	05059 HH CAP SCREW, 3/8-16 NC X 1 G5 ZINC			
16	15	05069 WHIZ LOCK, 1/4-20 NC X 5/8 ZINC			
17	2	05038 RUE RING COTTER #8			
18	1	10346 LINKAGE PIVOT			
19	2	03032 HANDLE BAR GRIPS (SOLD IN PAIRS)			
20	1	04526-01 FITTING, 6801-6-4			
21	1	03951 FILTER, HYDRAULIC OIL, WTH BY-PASS			
22	1	04212-OR-TR OIL FILTER MOUNT			
23	2	05225 CLAMP, 1-1/2" HOSE, CTB-35 ST			
24	1	10367 HOSE, RETURN			
25	1	00259 CONTROL VALVE ASSEMBLY			
26	1	00273 SPEED LEVER ASSEMBLY			
27	1	01503K CLUTCH LEVER KIT			
28	1	06423 STARTER GROMMET			
29	1	05556 HH CAP SCREW, 1/4-20 NC X 1-3/4 G5 ZINC			
30	1	05096 NUT, NYLOCK, 1/4-20 NC ZINC			
31	1	10362 FITTING, 4603-12-12			
32	2	05008 CLAMP, 1" HOSE, CTB-29			
33	1	10368 RETURN HOSE			
34	1	10534 HOSE COVER			
35	1	10548 SPRING LEE LE-055E-6MW			
36	2	03514 CABLE, 40"			
37	1	10549 BACK COVER			
38	1	03515-T THROTTLE CABLE			
39	2	05233 SCREW #10-24 X 1/2 PPH			
40	1	03045 CABLE, 47"			
41	1	03040-02 DECAL, "BARRETO", 3-1/2 X 11-1/4			
42	1	03341-24 DECAL, WARNING - NO PARKING			
43	1	03341-12 DECAL, DIGGIN BOOM, UP-DOWN			
44	1	04430-05 DECAL, DIG CHAIN FWD-N-REV			
45	1	04440 INSTRUCTION SHEET WICABLE			
46	1	10590 INSTRUCTION SHEET HOLDER			
47	1	04440-06 DECAL, WHEEL DRIVE F-N-R			




BARRETO

TITLE CONTROL ASSEMBLY

PRODUCT LINE: TRENCHER 912
SCALE: 1:8
SHEET 2 OF 2
DATE 3/10/04
DWG# 00260

REF. QTY.	PART NO.	DESCRIPTION
1 1	07006	ENGINE, 9 HP HONDA GX270
2 1	02016	PUMP ADAPTER
3 1	03021	JAW COUPLER, PUMP, 5/8" BORE
4 1	03022	SPIDER, RUBBER
5 1	03023	JAW COUPLER, 1" BORE L095
6 1	05014	KEY, 1/4 X 1/4 X 3/4
7 1	04507	PUMP SNP2-8-5HSTAT
8 1	04504	ADAPT PLATE KIT
9 1	04506	PG HYDROSTAT PUMP 63 CI
10 1	10242	ENGINE MOUNT PLATE
11 14	05101	WASHER, 3/8 SAE ZINC
12 6	05091	HH CAP SCREW, 3/8-16 NCX 1-1/4 G5 ZINC
13 4	05121	HH CAP SCREW, 3/8-16 NCX 1-3/4 G5 ZINC
14 4	05269	NUT, 3/8-16 NC GRB ZINC
15 1	10339	PUMP CABLE ARM
16 1	10340	CABLE BRACKET
17 1	04530	FITTING, 4601-16-12
18 1	04211	FITTING, 6801-8-10
19 2	04538	FITTING, 6801-6-6
20 2	04533	FITTING, 6801-8-8-LL
21 1	10545	PUMP COVER MOUNT
22 2	06038	RUE RING COTTER #8
23 2	05081	WASHER, 1/4 SAE ZINC
24 1	04536	FITTING, 9067-6-12METRIC
25 1	10588	ENGINE DRAIN HOSE
26 1	04539	FITTING, 2408-6
27 1	03341-07	DECAL, "IGNITION OFF/ON"
28 1	05240	SET SCREW, 6MM, CUP POINT

07009 OPTIONAL 9HP ROBIN ENGINE



NOTES:
 (1) ADAPT KIT INCLUDES PLATE,
 COUPLER, O-RINGS, BOLTS,
 WASHERS
 (2) SET SCREW INCLUDED


BARRETO

TITLE: ENGINE & PUMPS ASSEMBLY
 PRODUCT LINE: TRENCHER 912 DATE 3/17/04
 SCALE: 1:6 DWG# 00261
 SHEET 1 OF 1


BARRETO

TITLE: FRONT END ASSEMBLY

PRODUCT LINE: TRENCHER 9102
SCALE: 1:8
DATE: 3/17/04
SHEET 1 OF 2
DWG# 00262



REF. QTY.	PART NO.	DESCRIPTION
1 1	00264	MOTOR HOUSING ASSEMBLY
2 1	10347	FRONT TIRE, FLAT FREE
3 1	10273	FRONT END MOUNT
4 1	05046	NUT, GRIPCO, 1/2-13 NC G5 ZINC
5 1	05301	HH CAP SCREW, 1/2-13 NC X 6 G5 ZINC
6 1	03903	FLAP
7 4	05096	NUT, NYLOCK, 1/4-20 NC ZINC
8 4	05237	HH CAP SCREW 1/4-20 NC X 1 G5 ZINC
9 1	10376	FLAP KEEPER
10 1	10280	PIVOT PIN
11 1	05069	WHIZ LOCK, 1/4-20 NC X 5/8 ZINC
12 1	00265	ROLLER ASSEMBLY
13 1	10270	CUSHION, BOOM
14 1	10318	CUSHION WASHER
15 1	10319-F	CHAIN TENSION SCREW
16 1	10316, 10649, 10865	BOOM OPTIONS - 12", 18", 24"
17 1	10325, 10650, 10866	BOOM GUARD OPTIONS - 12", 18", 24"
18 1	10326	NUT, 1/2-13 NC G5 ZINC
19 3	05092	HH CAP SCREW, 3/8-16 NC X 1-1/2 G5 ZINC
20 2	10281	CYLINDER PIN
21 4	05304	HH CAP SCREW, 5/16-18 NC X 1/2 G5 ZINC
22 1	10458	SPACER, FRONT AXLE
23 1	CHAIN OPTIONS	CHAIN OPTIONS
24 1	10286	AUGER SPACER
25 1	10287	AUGER
26 4	10568	HH CAP SCREW, 3/8-24 NF X 3 G5 ZINC
27 1	00271	CYLINDER ASSEMBLY
28 2	05044	GREASE ZERK, 1/4-28 UNF
29 1	10546	CYLINDER ROD PIN
30 2	10564	CRUMBER MOUNT
31 2	05089	HH CAP SCREW, 5/16-24 NF X 2-1/4 G5 ZINC
32 2	10462	NUT, GRIPCO, 5/16-24 NF G5 ZINC
33 1	05307	GREASE ZERK, 1/4-28 UNF 90°
34 1	10567	CRUMBER ARM
35 2	05102	WASHER, 1/2 SAE ZINC HARDENED
36 2	10586	CLEVIS PIN, 1/2 X 2-3/4 ZINC
37 2	05222	COTTER PIN 1/8 X 3/4
38 3	05073	NUT, NYLOCK, 3/8-16 NC ZINC
39 3	04440-02	DECAL, DANGER, BOOM GUARD
40 1	04440-03	DECAL: 912
41 1	03341-05	DECAL: DANGER, CHAIN
42 1	10626	PIVOT PIN WASHER
43 1	10627	C-SINK HD CAP SCR. 31 X .75 NC 2 BEARING, 1/2 BORE
45 2	10347.50	



1 CUP CHAIN & SHARK CHAIN OPTIONS:
 12" BOOM, CHAIN, GUARD OPTION
 16" BOOM, CHAIN, GUARD OPTION
 24" BOOM, CHAIN, GUARD OPTION




BARRETO

TITLE: FRONT END ASSEMBLY

PRODUCT LINE: TRENCHER 912
 SCALE: 18
 SHEET 2 OF 2
 DATE 10/21/04
 DWG# 00262

REF. QTY.	PART NO.	DESCRIPTION
1	4	05572 SH CAP SCREW, 5/16-18 NC X 1 G5 ZINC
2	2	03226 O-RING, 2-112N70, 11/16 OD X 3/32 SECTION
3	1	10285 SEAL, CR22550 PN:
4	1	10284 SNAP RING, HO-334, 3-11/32 INTERNAL
5	1	05603 SNAP RING, HO-315, 3-5/32 INTERNAL
6	1	05607 SNAP RING, SH-156, 1-9/16 EXTERNAL
7	1	10253 BALL BEARING, SKF 6209
8	1	03943 BALL BEARING, SKF 6208
9	1	02065 MANIFOLD, TINE MOTOR
10	1	10450 MOTOR, 158-T 11.9 M-SPL
11	1	10254 HOUSING TUBE
12	1	10252 SPROCKET SPINDLE
13	1	03001 O-RING, 2-152, 3-7/16 OD X 3/32 SECTION
14	2	03302 FITTING, 6409-6 PLUG
15	2	05585 SH CAP SCREW, 1/2-13 NC X 1-1/4 G5 ZINC
16	4	05167 STUD, KNULED 1/2-20 X 1-13/16, PLT




BARRETO

TITLE: MOTOR / SHAFT ASSEMBLY

PRODUCT LINE: TRENCHER 912
SCALE: 1:4
SHEET 1 OF 1
DATE: 3/12/04
DWG# 00263

REF. QTY.	PART NO.	DESCRIPTION
1 1	00263	MOTOR/SHAFT ASSEMBLY
2 1	10248	DIG SPROCKET 100A12
3 4	05076	NUT, GRIPCO, 1/2-20 UNF
4 1	10255	CHAIN MOTOR HOUSING
5 8	05069	WHIZ LOCK, 1/4-20 UNC X 5/8
6 1	10283	HOUSING COVER
7 2	10277	BUSHING, NYLON, IGUS MF1-2024-16
8 2	04520	FITTING, 6400-8-B
9 1	05044	GREASE ZERK, 1/4-28 UNF
10 1	03040-04	DECAL, "GREASE DAILY"
11 1	11056	NUT, JAM, 1/2-13 NC G5 ZINC
12 1	10601	BRACE BOLT




BARRETO

TITLE: MOTOR HOUSING ASSEMBLY

PRODUCT LINE: TRENCHER 912
SCALE: 1:4
DATE: 3/1/04
DWG# 00264
SHEET 1 OF 1

REF.	QTY.	PART NO.	DESCRIPTION
1	2	03043	BALL BEARING, 6205
2	3	05024	SNAP RING, HO-200, .2" INTERNAL
3	2	01026	SHIELD, OUTBOARD BEARING
4	1	10311	CHAIN ROLLER
5	2	10312	ROLLER SPACER
6	2	10887	O-RING, 2-020N70, 1 OD X 1/16 SECTION
7	1	05044	GREASE ZERK, 1/4-28 UNF
8	1	05046	NUT, GRIPCO, 1/2-13 NC G5 ZINC
9	1	10320	ROLLER AXLE


REMOVE ONE SEAL FROM EACH BEARING
INSTALL BEARINGS WITH SEAL FACING OUTWARD



BARRETO

TITLE: CHAIN ROLLER ASSEMBLY
 PRODUCT LINE: TRENCHER 912 DATE: 3/11/04
 SCALE: 1/2 DWG# 00265
 SHEET 1 OF 1

REF. QTY.	PART NO.	DESCRIPTION
1 1	10243	LID
2 2	03060	BUSHING, NYLON, IGUS MFI-1012-06
3 1	03020	SEAL
4 1	03061	FELT WASHER, 5/8 X 1 X 1/8
5 1	05096	NUT, NYLOCK, 1/4-20 NC
6 1	05125	HH CAP SCREW, 1/4-20 NC X 1-1/4 G5 ZINC
7 1	10244	DUMP VALVE ARM
8 1	01211	DUMP VALVE LEVER
9 1	03241	LID GASKET
10 1	03242	MANIFOLD GASKET
11 1	10247	SUMP SCREEN#12 O-RING
12 12	05069	WHIZZ LOCK, 1/4-20 UNC X 5/8
13 1	10401	FITTING, 6400-6-6
14 1	10364	FITTING, 4601-16-12
15 2	05225	CLAMP, 1-1/2" HOSE, CTB-35 ST
16 1	10366	SUCTION HOSE
17 1	10526	FITTING, 6409-12 PLUG
18 1	04555	FITTING, 6801-4-4
19 1	05038	RUE RING COTTER #8
20 1	05081	WASHER, 1/4 SAE ZINC
21 1	03040-06	DECAL, "HYDRAULIC OIL ONLY"
22 1	03293	O-RING, 3-920N90, -20 FITTING



BARRETO

TITLE: LID ASSEMBLY

PRODUCT LINE: TRENCHER 912 DATE: 3/11/04
SCALE: 1/4 DWG# 00267
SHEET 1 OF 1


BARRETO

TITLE: TRANSMISSION ASSEMBLY


PRODUCT LINE: TRENCHER 912 DATE: 3/10/04
SCALE: 1:4 DWG# 00268
SHEET 1 OF 1

① KEY SUPPLIED WITH MOTOR
1/4 X 1" WOODRUFF PN 05013

REF.	QTY.	PART NO.	DESCRIPTION
1	1	10230	AXLE, RIGHT
2	1	10063	GEAR, WHEEL DRIVE, 36T X 1-1/4
3	1	02075	GEAR, WHEEL DRIVE MOTOR
4	1	05069	WHIZ LOCK, 1/4-20 UNC X 5/8
5	1	05542	WASHER, 1/4 FENDER PLAIN
6	6	05102	WASHER, 1/2 SAE ZINC HARDENED
7	6	05067	HH CAP SCREW, 1/2-13 NC X 1 G5 ZINC
8	2	03280	BALL BEARING, SKF 6206
9	8	05237	HH CAP SCREW 1/4-20 NC X 1 G5 ZINC
10	1	05015	KEY, 5/16 X 5/16 X 1-1/4
11	2	05214	SNAP RING, 1-1/4" EXTERNAL, SH-125
12	4	10219	GEARBOX SPACER
13	1	10229	TRANSMISSION PLATE, L
14	1	10228	TRANSMISSION PLATE, L
15	1	04502-F	WHEEL DRIVE MOTOR 22.6 CI, T158-1048
16	1	10183	BEARING HOUSING, AXLE
17	1	10235	BEARING HOUSING, AXLE
18	1	05034	SNAP RING, 1-3/16 EXT, SH-118
19	2	05585	SH CAP SCREW, 1/2-13 NC X 1-1/4 G5 ZINC




REF. QTY.	PART NO.	DESCRIPTION	REF. QTY.	PART NO.	DESCRIPTION
1 1	00247	BODY ASSEMBLY	24 1	10550	CYLINDER HOSE, TOP / PISTON
2 1	00261	ENGINE & PUMP ASSEMBLY	25 1	03341-04	DECAL, CAUTION AVOID INJURY
3 10	05101	WASHER, 3/8 SAE ZINC	26 1	03040-01	DECAL, "MADE IN USA"
4 4	05057	HH CAP SCREW, 3/8-16 NC X 3/4 G5 ZINC	27 4	05049	WHZ LOCK, 1/4 X 3/4
5 1	00262	FRONT END			
6 1	00260	CONTROL ASSEMBLY			
8 6	05059	HH CAP SCREW, 3/8-16 NC X 1 G5 ZINC			
9 6	05073	NUT, NYLOCK, 3/8-16 NC			
10 1	10365	VENT HOSE ASSEMBLY			
11 1	10369	HOSE, PUMP OUTPUT			
12 1	10412	HOSE, CHAIN MOTOR, TOP			
13 1	10413	HOSE, CHAIN MOTOR, BOTTOM			
14 1	10414	HOSE, HYDROSTAT SUCTION			
15 1	10372	HOSE, HYDROSTAT, RIGHT			
16 1	10373	HOSE, HYDROSTAT, LEFT			
17 4	05102	WASHER, 1/2 SAE ZINC HARDENED			
18 4	05323	HH CAP SCREW, 1/2-13 NC X 1-1/4 G5 ZINC			
19 1	10415	HOSE, HYDROSTAT RETURN			
20 1	10544	PUMP COVER			
21 8	05081	WASHER 1/4 SAE ZINC			
22 4	05096	NUT, NYLOCK, 1/4-20 NC			
23 1	10551	CYLINDER HOSE, BOTTOM / ROD			



BARRETO

TITLE: 912 ASSEMBLY


PRODUCT LINE: TRENCHER 912
SCALE: 1:12
SHEET 1 OF 1
DATE: 8/26/04
DWG# 00269



BARRETO

TITLE: CYLINDER ASSEMBLY
2.5 X 5.75" STROKE
PRODUCT LINE: TRENCHER 912 DATE: 8/26/04
SCALE: 1/4 DWG# 00271
SHEET 1 OF 1

REF	QTY	PART NO	DESCRIPTION
1	1	10521	SPEED LEVER PIVOT
2	1	10523	SPEED LINK
3	1	10519	SPEED CABLE ARM
4	1	10524	SPEED LEVER
5	2	03029-04	BUSHING, NYLON, MICRO PLASTICS 12SWS1048
6	1	10520	SPEED LEVER MOUNT
7	1	10525	SPACER
8	2	10100	BUSHING, NYLON, IGUS MFL-0810-05
9	2	10509	BUSHING, NYLON, IGUS MFL-0608-06
10	1	10113	THRUST WASHER, .518 X .873 X .030
11	3	05506	SNAP RING, 1/2" EXTERNAL, SH-50
12	1	05235	SH CAP SCREW, 1/4-28 NF X 3/4 G5 PLAIN
13	1	05243	HH CAP SCREW 1/4-28 NF X 1-3/4 G5 ZINC
14	1	05266	NUT, GRIPCO, 1/4-28 NF GRB
15	1	05101	WASHER, 3/8 SAE ZINC
16	1	05283	NUT, GRIPCO, 3/8-24 NF GRC
17	5	05081	WASHER, 1/4 SAE ZINC
18	4	05038	RUE RING COTTER #8
19	1	10547	SPEED LEVER ROLLER
20	1	03508	SPEED KNOB
21	1	11031	SPEED LEVER SPACER
22	1	03029-02	CLEVIS PIN, 1/4 X 1-5/8




BARRETO

TITLE: SPEED LEVER ASSEMBLY
 PRODUCT LINE: TRENCHER 912 DATE: 2006
 SCALE: 1:4 DWG# 00273
 SHEET 1 OF 1

WHEEL DRIVE NEUTRAL ADJUSTMENT


The speed control cables may need to be adjusted after some use. If the machine creeps while the speed control is in neutral, the speed cables will need adjustment. Adjust the cables to bring the pump cable arm to the neutral position (vertical) when the speed control also is in neutral. Adjust the cables to eliminate slack, but do not over tighten them so they are extremely tight against each other.



WHEEL DRIVE VALVE CABLE ADJUSTMENT

The clutch cable and lever must have some free play. The cable will stretch and occasionally needs adjustment.

1. Rotate the actuator arm clockwise, by hand, to take up any free play. Measure the distance from the pin of the actuator arm to the end of the cable housing.
2. Pull the clutch lever all the way up until it touches the handle bar grip. With the lever pulled up, again measure the distance from the pin of the lever to the cable housing. Calculate the difference.
3. Adjust the cable for $7/16"$ to $1/2"$ movement of the actuator arm at the pin. Do not include any lever free play in the measurements.




BARRETO	
66498 HWY 203 LA GRANDE, OR 97850 (541) 963-7348	DMM APP
DATE	REV DESCRIPTION

MASS: 30.67520 POUNDS

NOTES:

1. MATERIAL:

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
14	10733	CONTROL MOUNT BRACE	1
15	05068	WASHER, 5/16 SAE ZINC	4
16	10462	NUT, GRIPCO, 5/16-24 NF	4
17	05052	HH CAP SCREW, 5/16-24 NIF X 3/4 G5 ZINC	4



TOLERANCES UNLESS OTHERWISE SPECIFIED

FRACTIONS: $\frac{3}{16}$ = $\pm \frac{1}{16}$, $\frac{1}{8}$ = $\pm \frac{1}{16}$, $\frac{1}{4}$ = $\pm \frac{1}{32}$, $\frac{1}{2}$ = $\pm \frac{1}{64}$

DECIMALS: $X = \pm .1$, $.XX = \pm .03$, $.XXX = \pm .005$

ANGLES: $\pm 2^\circ$

PRODUCT LINE: TRENCHER 912

SCALE: 1:12

DWG# 10327-BRACE-ASY

SHEET 1 OF 1

14


66498 NAVY 203
LA GRANDE, OR 97850
(541) 963-7348

DATE	REV	DESCRIPTION	DRAWN APP


MASS: 230.5468 POUNDS


NOTES:


1. MATERIAL





TOLERANCES UNLESS OTHERWISE SPECIFIED	TITLE X
EXACTS:	X
±0.01/16 = ±1/16	XX = ±.1
1/32 = ±1/32	XXX = ±.03
1/64 = ±1/64	XXXX = ±.005
DECIMALS:	ANGLES:
X = ±.1	.2°
XX = ±.03	
XXX = ±.005	
PRODUCT LINE:	
SCALE: 1:1	
SHEET 1 OF 1	DRAW# MANUAL-LUBE














GREASE